

Mini Recorder Instruction

1. Please switch to "ON" when recording, then the indicator is flashing in red for 5s, the recorder started, switch to "OFF", the red light is off and save the recording, the recording stop working.
2. Recording format support MP3, do not operate the recorder while charging.
3. Ensure to inset TF card before recording.
4. The recorder need connecting to computer via USB to charged, and it will take 2-3 hours. the indicator will flash while in charging status, the indicator will become red when fully charged.
5. the recording time is about 5 hours.
6. TF card recording size: 2GB, about 20 hours.

隨身錄音碟使用說明

1. 當錄製時，請切換到 "ON"，顯示器閃爍 5 秒，錄製開始，切換到 "OFF"，紅燈關閉並保存錄音，錄音停止工作。
2. 錄音支援 MP3 模式，當充電時，不要操作答錄機。
3. 在錄音前確保插入 TF 卡。
4. 答錄機需要通過 USB 連接到電腦上充電，需要 2-3 小時。在充電狀態下指示燈閃爍，當電量滿時指示燈變為紅色。
5. 錄製時間大約為 3 小時。
6. TF 卡錄製大小：2GB，大約 20 小時。